


INTRODUCTION TO ENERGY EFFICIENCY IN

7811

PRISONS, EMERGENCY BUILDINGS AND COURTS



1EB62

CONTENTS

SECTION	PAGE
1. INTRODUCTION	2
2. ENERGY MANAGEMENT	3
3. ACTION PLAN	6
4. MEASURES TO ACHIEVE ENERGY SAVINGS	7
5. ENERGY USE IN PRISONS, EMERGENCY BUILDINGS AND COURTS	13
6. COMPARING WITH ACCEPTED STANDARDS - PERFORMANCE INDICES	15
7. A CLOSER LOOK AT ENERGY CONSUMPTION	17
8. CASE STUDIES	19
9. ADVICE AND HELP	22
APPENDIX 1 - Development of Building Performance Indices (PI)	25
APPENDIX 2 - Energy Conversion Factors	28

INTRODUCTION

1.1 Who this guide is intended for

This guide is aimed at managers who have responsibility for prisons, emergency buildings or courts. It should also be of interest to energy managers who are responsible for estates which include such buildings.

It is intended to introduce the steps that anyone responsible for energy needs to take in order to control and reduce energy consumption. It shows how to gain an understanding of energy use in prisons, emergency buildings and courts and indicates the methods by which savings are likely to be made.

1.2 Use of the guide

This guide is one of a series for different types of building. A full list of titles is given in section 9.4; make sure that you have the guide most suited to your needs.

The guide covers Crown and Combined Courts, but not County Courts. If you are responsible for County Courts, the guide on offices may be more relevant to your needs.

If you are unfamiliar with energy management, you should start with section 2, Energy Management, in order to get an overview of the subject.

- The subsequent sections concern creating and following an action plan (section 3) and implementing measures to achieve energy savings (section 4). Sections 5 to 7 describe methods for assessing energy use in prisons, emergency buildings and courts.
- The case studies (section 8) give examples of buildings where energy saving measures have been successfully implemented.

- Section 9 lists further sources of help and information, including addresses for obtaining copies of the information referred to throughout the guide.

More experienced energy managers or consultants may use the action plan (section 3), or the suggested measures (section 4) as aide-memoires. They may also use the method for calculating performance indices described in section 6 and appendix 1.

A manager responsible for energy on a number of different sites may wish to distribute the guide to the person responsible for energy management at each site.

1.3 Environmental benefits of energy efficiency

Most of the energy used today originates from fossil fuels (gas, oil and coal). Burning fossil fuels emits pollutants, including gases that cause acid rain, and carbon dioxide. As carbon dioxide and other gases build up in the atmosphere, more of the sun's heat is trapped (the greenhouse effect). This could result in the earth becoming hotter (global warming), which may also increase the risk of storms, coastal flooding and drought. Using energy more efficiently is one of the most cost effective means of reducing emissions of carbon dioxide and also helps to conserve finite reserves of fossil fuels.

1.4 Financial benefits of energy efficiency

Using simple and cost effective measures, fuel bills can often be reduced by an average of about 20%. Further savings are possible in new construction and when buildings are refurbished or their services replaced.

Well designed and efficiently managed services not only result in energy savings, but also in an improved and more comfortable working environment. This can give rise to better productivity and reduced absence due to sickness.

Efficiently run buildings also require less manpower to service complaints, providing savings additional to the reduced costs of energy.

1.5 Acknowledgements

This guide was prepared for the Energy Efficiency Office (EEO) by Target Energy Services Ltd. The EEO gratefully acknowledges the assistance given by the following organisations in providing information:

Building Energy Solutions
Leicestershire County Council
Lord Chancellor's Department
Norwich Combined Court

ENERGY MANAGEMENT

2.1 Energy efficiency - a management issue

The aim of energy management is to ensure that energy use and energy costs are as low as possible while standards of comfort, service and productivity are maintained or improved. This requires somebody to be directly responsible for energy efficiency, even if this is only a part of their job:

- As a rule of thumb, organisations or sites with an energy bill over £1 million may justify the employment of a full time energy manager. Otherwise, energy management will normally be combined with other responsibilities.
- Each building should have someone responsible for energy management.
- In larger organisations, energy efficiency should also be managed centrally.
- Energy efficiency must be strongly supported at the highest levels with the authority and resources needed for initiatives to be effective.

Encourage your management board to sign up to the EEO's Making a Corporate Commitment campaign if it has not already done so (see section 9.5).

The duties and functions of an energy manager are discussed here. Section 3 includes a suggested action plan which can be used to get things moving.

2.2 Actions and measures to save energy

One of your main activities should be to identify areas of energy waste and implement energy saving measures to reduce them. Some waste is simple to diagnose and to correct, for example lighting left on all night in unoccupied areas. Other waste may be more difficult to identify and take more expertise or resources to correct (see section 4).

2.3 Controlling energy use

To control energy consumption and costs, regular and reliable records of energy use should be maintained. Such records will help to identify changes in energy costs and consumption. This is commonly called monitoring and targeting or M&T. The simplest arrangement is a form which can be filled in regularly for each fuel, recording monthly energy use. Alternatively, systems can be based on a computer spreadsheet, or commercially available systems can be purchased. Computer based systems are

essential for effective monitoring of a large estate or site.

An M&T system should:

- Record energy consumption and any other factors that affect energy use (building usage, weather, productivity, etc).
- Compare your energy use to previous years, to other buildings of the same type, or to yardsticks representing typical or target energy performance.
- Alert you to sudden changes in energy use patterns as soon as possible, so that any increase can be investigated and corrected if appropriate.
- Produce regular summary reports, especially if there are many sites, to confirm performance and show savings achieved overall.

If fuel bills are not available or some are missing, then duplicates can usually be obtained on request from the relevant fuel supply company. Meters should be checked every few months to ensure that billed readings are correct. In shared or multi-meter sites ensure you are being billed for your use; label your meters.

For further information see:
EEO Practical Energy Saving Guide For Smaller Businesses.

Example recording of monthly electricity use

Period: JAN-DEC 92

Completed by: NJK

Date: 10.2.93

Meter Reading Date	kWh Used	Cost £
8.1.92	39,700	2756.29
5.2.92	38,700	2653.65
5.3.92	31,500	2200.35
9.4.92	25,000	1584.02

2.4 Getting on the right tariffs

Making sure that fossil fuels and electricity are purchased at the cheapest rates is increasingly important. Considerable cost savings are sometimes possible by changing to more suitable tariffs for electricity, or by making alternative supply arrangements.

Tariff savings usually incur little or no initial cost and may be used to help finance measures to reduce energy costs further. Reviewing tariffs should therefore be one of your first actions:

- Seek alternative electricity tariffs from your existing supplier.
- Consider using other electricity suppliers in the contract market when the supply is for more than 100 kW (representing a bill of around £30,000 a year).
- Consider a different supplier for oil, or for gas supplies over 70,000 kWh a year (representing a bill of around £1,000 a year).

- For large sites with complicated tariffs and load patterns, it may be worth employing a tariff consultant, although be aware of consultants' costs (contact the Energy Systems Trade Association (ESTA) or the Major Energy Users' Council, see section 9.9).

For further information see:

Fuel Efficiency Booklet 9
Economic use of electricity in buildings.

2.5 Motivating occupants and staff

The greatest possible savings can only be achieved with the cooperation of staff. Foster their support and give them every chance to participate in energy saving initiatives. Feed back information to staff on the results of these initiatives.

Activities could include:

- Providing information about why energy conservation is important, describing practical and environmental benefits
- Setting up an incentive scheme
- Stressing that most energy is used by all occupants - for lighting, equipment and for maintaining comfortable conditions
- Encouraging staff to switch off equipment and lighting when it is not needed, by providing information and training on how to operate systems and controls, through stickers, posters and articles in staff magazines
- Relating energy use at work to energy use at home.

You should monitor the savings achieved and publicise them to help motivate staff and senior management. Obtaining capital investment for future energy efficiency measures may depend on demonstrating the cost effectiveness and the environmental benefits of measures that have already been completed.

For further information see:

EEO Good Practice Guide 84 - Managing and motivating staff to save energy.

2.6 Energy management in larger organisations

In larger organisations with estates of buildings, an energy manager may be responsible for many separate locations. He or she will have a different role from a site energy manager which is not addressed in detail here.

For further information see:

EEO General Information Report 12 - Organisational aspects of energy management

EEO General Information Report 13 - Reviewing energy management

Making a Corporate Commitment - various guides .

2.7 Responsibilities in larger buildings


In larger buildings, a number of groups should be involved in energy management:

- Senior management
- Local or departmental management
- Facilities management
- Plant operators
- Security staff
- Maintenance contractors.

You should have regular contact with all of the above and with the individual building occupants. A facilities manager often makes a good energy manager because they already have close contact with staff. You should find out about factors relating to occupants' comfort, including:

- How plant and equipment controls are set and who is responsible for their adjustment
- How comments from occupants are acted on - especially those reflecting dissatisfaction.

Energy Efficiency Poster



2.8 Security and emergency considerations

The security aspects of prisons, courts and police stations are paramount and have to take precedence over potential energy efficiency measures. Equally, standby arrangements necessary to respond to a wide range of emergencies can force up consumption. However, you should ensure that security lighting and standby facilities are provided in the most efficient manner possible without compromising security and emergency issues.

In order to achieve this, you need to work closely with the security staff and departmental managers in order to reach mutually acceptable solutions. Keeping these groups informed and aware will help gain their commitment to the energy campaign.

Improving external lighting can enhance security, often with associated reductions in energy consumption, if energy efficient lights are used.

2.9 New and refurbished property

Energy efficiency measures are most cost effective when installed in new or refurbished buildings, or while replacing equipment which is at the end of its normal life. New items of equipment which are required anyway should be as efficient as possible. Additional items to improve energy efficiency can be installed most cheaply during other building work. These special opportunities to incorporate energy efficient design are relatively rare and should not be missed.

You should be involved in decisions about new or refurbished property and should not just be brought in to correct high energy use following decisions made by others. Your knowledge of how the building is

used should be drawn on when specifying appropriate levels of services and controls.

When moving or refurbishing office premises, take the opportunity to select or specify:

- Energy targets
- The level of services - for example the inclusion of full or partial air conditioning may double overall energy costs
- Systems which are simple and within the capabilities of the occupants to manage
- High efficiency of major plant and equipment such as boilers or main lighting systems
- Good levels of insulation
- Appropriate controls for the anticipated pattern of use
- Suitable metering and monitoring facilities
- Information, advice and training for staff in the use of new systems.

For further information see:

EEO Good Practice Guide 71 -
Selecting air conditioning systems.

2.10 Getting help

Sources of further information are described and listed in section 9.

To obtain further information about possible energy saving measures (see section 4), contact relevant manufacturers, installers or service providers who will advise you of the features of their products. Make sure that these features are relevant and appropriate to your requirements. Gas and electricity suppliers can also offer advice.

If time is not available or if discussions with a selection of competing suppliers do not provide a consistent picture, it may be worth hiring a professional consultant to provide advice or to conduct an energy survey.



Refurbishment offers a rare opportunity to incorporate many energy efficiency measures.

If the availability of finance and management time is a problem for opportunities requiring substantial investment, contract energy management (CEM) organisations may provide a solution - they offer a comprehensive service including finance and management responsibility. ESTA can provide a list of companies (see section 9.9).

For further information see:


Choosing an Energy Efficiency
Consultant (EEO)

3

ACTION PLAN

This flow diagram presents a step by step procedure to achieve cost savings in a building or a single site by bringing energy consumption and cost under control. It refers to other parts of this document for further guidance.

Produce your own action plan with these headings, showing specific actions and projects, each with target completion dates. The plan should be consulted frequently and reviewed annually.



MEASURES TO ACHIEVE ENERGY SAVINGS

4.1 Initial measures

In most buildings it is possible to make some savings by using the existing building and equipment as efficiently as possible. No financial investment is needed; instead, a check on how the building is being used may reveal areas where equipment can be turned off when it is not needed, or where the level of service can be reduced without affecting the comfort of occupants.

Some opportunities may be easy to identify and implement, such as altering thermostats or timeclocks. Others, such as turning lights off when rooms are not being used, may require the cooperation of staff. Motivating staff to help is therefore important, although a long term task. The list below indicates the type of items to check in an initial assessment of 'good housekeeping' opportunities. An exercise to review energy purchasing tariffs (see section 2.4) should be carried out at the same time.

Checklist of Initial Energy Saving Measures

Space and water heating

- Consider fuel switching (if your boiler can operate using more than one fuel).
- Check that time switches are set to the minimum period and ensure that room thermostats and radiator controls are on minimum settings commensurate with comfort conditions.
- Ensure that only occupied areas are heated, and that heating is off or reduced in non-working hours.
- If you have a building energy management system (BEMS), check that it is operating correctly and ensure that operators are trained to use it effectively.
- Reduce temperature of stored domestic hot water by turning down the thermostat to a minimum of 60°C, but no lower because of the risk of Legionella.
- Make sure that pumps are running only when required.

Lighting

- Ensure that someone is responsible for switching off in each room or area when not in use.
- Make the best use of daylight by keeping windows and roof lights clean and by

using working areas near windows where possible; encourage staff to turn off lights when daylight is good.

- Investigate existing lighting controls to see if the hours of use of artificial lighting can be reduced.
- Install 'task' lighting where this means that background artificial lighting levels or hours of use can be reduced.
- Avoid excessive lighting levels and hours of use in corridors. Where fluorescent lighting is used, it may be possible to reduce the number of tubes in luminaires.

Ventilation

- Ensure the main ventilation plant and toilet extractor fans are switched off outside occupied hours.
- Check that windows are not being opened to avoid overheating during winter.
- Ensure kitchen fans are switched off when no cooking is taking place.

Air conditioning

- Set temperature controls for cooling to 24°C or higher - lower settings require more cooling energy and may be 'fighting' the heating.

- Where the design permits, ensure heating and cooling are not on at the same time in the same part of the building (the advice of a consultant or on site services engineer may be needed).

- Make sure that refrigeration plant such as chilled water systems do not run unnecessarily.

- Ensure that fans and pumps do not run when not required.

Office equipment

- Encourage staff to turn off office equipment when it is not being used, particularly at break times and at the end of the working day.

Controls

- Ensure all controls are labelled to indicate their function and, if appropriate, their new reduced settings.
- Establish responsibilities for control setting, review and adjustment.

Building fabric

- Ensure all insulation is in a state of good repair.

4.2 Maintenance

Regular maintenance is a prerequisite to controlling energy costs and is also essential for maintaining a healthy environment in buildings. A maintenance programme should include:

- Replace filters at the manufacturer's recommended intervals and keep heat exchanger surfaces, grilles and vents clean in order to allow unobstructed flow of air
- Check plant operation and controls regularly
- Ensure that all motorised valves and dampers fully open and close without sticking
- Check that thermostats and humidistats are accurate
- Check calibration of controls
- Service the boiler plant and check combustion efficiency regularly
- Look for water leaks and carry out repairs where necessary
- Clean windows to maximise daylighting
- Replace 38mm diameter fluorescent tubes in switch start fittings with 26mm diameter high efficiency triphosphor tubes as the former expire (see diagram on page 12)
- Clean lamps and luminaires regularly and replace at the manufacturer's recommended intervals.

4.3 Longer term measures

There will almost certainly be items of equipment or insulation which could be replaced with more efficient alternatives. The main areas for savings, starting with the most cost effective, are:

- Control systems
- Lighting and office equipment
- Heating and air conditioning plant
- Building fabric.

Care is required in deciding which measures to implement and the most

effective way of carrying them through. In the first instance, measures should be undertaken which have as many of the following features as possible:

- Worthwhile energy and cost savings
- Low capital cost
- Short period to repay initial cost
- Little technical knowledge required
- Little or no extra maintenance
- Little or no disruption to normal operations.

Further information is given in references listed in section 9 - note particularly:

EEO Fuel Efficiency Booklets:

- 1 Energy audits for buildings
- 8 The economic thickness of insulation for hot pipes
- 10 Controls
- 12 Lighting

EEO Good Practice Guides:

- 35 Energy efficient options for refurbished offices
- 46 Heating and hot water systems in offices

Energy Efficient Lighting in Offices. A THERMIE Maxibrochure.

Assessing costs of measures

The cost effectiveness of an energy efficiency investment can be expressed as the initial cost divided by the monthly or annual cost savings - the simple payback period.

More sophisticated appraisal techniques for comparing different investments, such as 'discounted cash flow' methods, are sometimes used in larger organisations and for major investments. If these are needed, advice should be sought from those who use these methods. If energy-saving initiatives are taken during refurbishment or when moving buildings, capital cost is often substantially reduced and interference with normal working practices is kept to a minimum.

For measures included during replacement or refurbishment, the

initial cost (for calculating the payback period) is only the over-cost: for example, the extra cost of a high efficiency 'condensing' boiler compared with a conventional boiler. This reduces payback periods and increases cost-effectiveness.

In some cases, energy efficiency measures can reduce overall capital costs, such as providing natural ventilation which avoids the need for air conditioning.

Where shortage of funds and/or lack of expertise is holding up promising measures, it may be worth considering contract energy management as described in section 2.10.

Measures can be split into those which require limited attention such as insulation, and those which require management time to ensure that they continue to be effective, such as building energy management systems. For the latter, manageability is as important as the potential for energy savings, and should be a prime consideration in the design.

Heating system

The cost of providing heat for space heating or hot water depends on the cost of the fuel used, the efficiency of conversion of fuel to heat, and the extent of the distribution losses in supplying the heat when and where it is needed.

Fossil fuels such as gas, oil or coal are usually burnt in a boiler and the heat is transferred to a heating system. Boilers have varying seasonal efficiencies - old boilers may convert less than 50% of the energy content of the fuel into heat in the heating system. The most efficient systems include gas condensing boilers and combined heat and power (CHP) installations. Condensing boilers can achieve seasonal efficiencies of over 90% and can be used with most existing heating systems. They ought to be considered whenever boilers are

replaced. CHP systems should be considered in buildings with continuous demands for heat and power, particularly prisons.

Heat is lost from the heating system through ductwork, pipework, valves and hot water storage tanks. Pipe runs should therefore be short, and all parts of the system well insulated. Heat should only be supplied to a space or to produce hot water where and when it is needed. Where possible, large boilers should not be operated to meet small loads, as the efficiency will be very low.

Effective heating controls are essential. Types of control include:

- Simple time control: a time switch that turns heating on and off at a fixed time each day - seven day time switches allow for variable occupancy during the week
- Optimum start control: switches the heating on so that the building reaches the desired temperature just in time for occupation
- Weather compensation: varies the heating according to the outside temperature
- Room thermostat: keeps the temperature in a room to a required level
- Thermostatic radiator valves (TRVs): regulate the flow of hot water through the radiators in a room in order to maintain a local temperature
- Boiler sequence control: enables only the number of boilers required to meet the system demand.

The 1990 Building Regulations specify that new non-domestic buildings should have time controls and weather compensation, room thermostats or TRVs, and that large buildings should also have optimum start control.


HEATING MEASURES

- Separate the heating system into zones so that areas of the building with different heating requirements can be controlled separately.

- Fit TRVs in rooms which are prone to over-heating, due to solar gain, for example.
- Upgrade heating controls to include a seven day programmable timer, optimum start control and weather compensation as a minimum.
- Where small volumes of domestic hot water are required a long way from the main heating plant, consider installing local instantaneous water heaters.
- Install spray taps where possible.
- Insulate hot water tanks and boilers, and all pipework, valves and flanges which do not provide useful heat to occupied spaces.
- Consider replacing large central boiler plant with local, decentralised systems.
- Replace an old boiler installation with one that provides a minimum seasonal efficiency of at least 80%, preferably including at least one condensing boiler. Specify multiple boilers with a sequence controller rather than one large boiler in installations over 100kW, with the most efficient boiler leading the firing sequence.
- Use night setback controls in areas where background heating is required at night.
- Consider using combined heat and power.
- Ensure that boilers can only run when there is a heat demand. Unnecessary firing is known as "dry-cycling" and is often remedied by correctly wiring the boiler thermostat into the control system. In multi-boiler installations, wide band thermostats often overcome dry-cycling.
- Install a heater other than the main boiler to produce domestic hot water, and turn off the main boiler during the summer.
- Install destratification fans to move warm air from roof level to floor level in high ceiling buildings.

COMBINED HEAT AND POWER

CHP plant provides both electricity and heat. The fossil fuel supplied to the plant displaces high cost



electricity. As the heat which is inevitably produced is used for heating rather than being wasted, it is a more energy efficient means of generating electricity than conventional power stations. Overall efficiencies are typically 60-80%.

It is essential that the CHP plant is sized correctly in order to maximise the hours it runs and hence the savings achieved. This generally means matching the plant to the base load energy demands on the site. When assessing heat loads, take account of space heating, laundry and domestic hot water systems. CHP is usually cost effective if it runs for greater than 4,500 hours/year, so it is particularly suited to prisons.

CHP should be installed under a long term service contract with the supplier. The contract should specify the periods when essential maintenance should take place. It should also include penalty clauses for non compliance to reduce the risk of increased electricity maximum demand tariff charges which would occur when the CHP plant was not running, even for the shortest period. This is particularly important during winter when maximum demand charges are at their highest. Any prolonged stoppage will also result in an increase in electrical consumption leading to higher overall energy costs.

MECHANICAL VENTILATION AND AIR CONDITIONING

Mechanical ventilation provides air which is filtered and heated. Air conditioning additionally provides cooling and humidity control.

Pumps and fans consume a considerable amount of energy; in air conditioned buildings they consume at least half, and often more, of the total energy used for air conditioning.

Cooling is usually provided by an electrically driven refrigeration plant. Cooling systems should be controlled and insulated in the same way as heating systems. The savings will be proportionally higher as cooling is considerably more expensive to produce than heat.

MECHANICAL VENTILATION AND AIR CONDITIONING MEASURES

- Install variable speed controls on fans and pumps; these allow motor speeds to be controlled according to the demand instead of running at full power continuously.
- Set the temperature required for cooling as high as possible (24°C or higher) to reduce the demand for refrigeration.
- Ensure that controls are set or improved to avoid both heating and cooling air at the same time.
- Ensure that air conditioning systems make use of outside air for 'free cooling' whenever possible.

- When heating or mechanical cooling is required, ensure that the proportion of air recirculated within the building is as high as possible within the requirements for minimum fresh air rates.
- If humidifiers are being specified or replaced use ultrasonic humidification (but ensure that precautions are taken to avoid Legionella).
- Explore the opportunities for heat recovery from any source of warm exhaust air but bear in mind the increase in pump and fan power that will be required.

BUILDING FABRIC

Simple roof insulation and draught proofing are usually cost effective at any time, but most other building fabric measures are most cost effective when they form part of general maintenance or refurbishment. Improvements to the building fabric will be most cost effective in buildings which are in use 24 hours a day.

Caution: Insulation measures should be checked for condensation and water penetration risks.

BUILDING FABRIC MEASURES

- Insulate roof voids.
- Draught proof around windows and doors.
- Fit secondary glazing.
- Install cavity wall insulation or internal or external insulation.
- Reduce excessive glazing areas by replacing the glass with insulated wall panels.

- If windows are being replaced, fit multiple glazing, preferably with low emissivity glass which reduces heat loss in winter.

LIGHTING

Good savings can be achieved by ensuring that lighting equipment and its controls and management are of a high standard.

The energy used for lighting depends upon the energy consumption of the lamps and the hours of use. The most efficient systems are well designed, and have efficient lamps and fittings which provide the required level of illuminance (without over-lighting). They have controls which enable the lights to be switched off when they are not required, whether because a space is not being used or because there is sufficient daylight.

All new lighting in offices must comply with the Health and Safety (Display Screen Equipment) Regulations 1992 which implement the 1990 European Directive 90/270/EEC. Lighting for existing workstations must comply by 31 December 1996. Wherever lighting is upgraded, it offers an opportunity to select the most energy efficient options.

Some types of lamps, in order of increasing efficiency, are:

- 'Domestic' tungsten bulbs - very inefficient; should usually be replaced
- Tungsten spotlights - used for display lighting; even the most efficient lamps are much less efficient than fluorescent lamps
- Compact fluorescent lamps - efficient replacements for tungsten bulbs, although not as efficient as modern tubular fluorescent lamps
- Fluorescent tubes - used in most office areas
- Metal halide and sodium discharge lamps - these vary in efficiency depending on type (most are more efficient than fluorescent tubes). Sometimes used in uplighters; well suited to lighting large areas such as car parks.

Luminaires, left to right: recessed mirrored reflectors with louvres, batten fittings, opal and prismatic diffusers.

Photographs supplied by Philips and Fitzgerald.




Figure 4.1 Typical relative energy consumption

lamp type	typical energy consumption relative to tungsten bulbs for similar levels of lighting (%)
tungsten filament bulb	100
tungsten halogen spotlight	70
high pressure mercury (MBF)	22
compact fluorescent with electronic ballast	18
metal halide (MBI)	15
high pressure sodium	11
lower pressure sodium	7
Fluorescent tubes:	
(1) choke & starter control gear with 38mm diameter tubes	18
(2) as 1), but 26mm diameter high efficiency triphosphor tubes	16.5
(3) as 2), but with electronic ballast	13

Tungsten bulbs typically have a life of about 1,000 hours, while fluorescent and discharge lamps typically last for 8,000 hours or more. Removing tungsten bulbs therefore gives substantial savings in maintenance costs in addition to any energy savings.

Typical levels of energy consumption of different types of

lamp, expressed as a percentage relative to tungsten lamps, are given in figure 4.1.

These figures give an indication of the typical savings which may be made by replacing lamps with more efficient alternatives. For example, replacing an old inefficient tubular fluorescent system (1) with a modern efficient system (3) would

Compact fluorescent lamps.



reduce energy consumption by a factor of 13/18, a reduction of about 30%.

As well as lamps, light fittings (luminaires) contain a number of other elements, including:

- Diffusers or louvres - these are designed to give a good distribution of light without glare. Luminaires with prismatic and especially opal diffusers are less efficient than those with reflectors.
- Control gear - fluorescent and other discharge lamps need control gear to strike up and maintain light output. Old fluorescent luminaires have chokes and starters; modern electronic controls (ballasts) are more efficient.


Lighting controls should be used to ensure that, as far as possible, lights are off when they are not needed. It should be possible to control lights in each area of the building from local switches. Some automatic control may also help to reduce the length of time for which lights are left on.

Automatic lights include:

- Time controls - allow any group of lights to be switched on or off automatically at set times of the day.
- Presence detectors - automatically switch lights on when somebody enters a space, and off again after the space is vacated.
- Daylight detectors - allow groups of lights to be switched off or on according to the level of daylight. Some lights can also be dimmed as daylight levels alter.

LIGHTING MEASURES

- Replace tungsten lamps with compact fluorescent lamps or, better, with tubular fluorescent lamps.
- Replace tungsten spotlights with low voltage tungsten halogen lamps.
- Replace existing control gear in fluorescent fittings with electronic, high frequency ballasts.



The parts of a fluorescent light fitting

- Replace diffusers in tubular fluorescent fittings with reflectors and reduce the number of tubes if possible.
- If light fittings are over 15 years old, replace with new efficient fittings and consider installing new lighting controls.
- Use metal halide or sodium discharge lamps for outside areas such as car parks.
- Improve lighting controls, including:
 - local manual switching for all lights except security lights
 - time controls for areas with regular patterns of use
 - time controls or daylight detection controls for external lighting
 - presence detection controls for corridors and stairs (excluding emergency lighting) and for areas which are infrequently used
 - daylight detection controls for lighting adjacent to windows.

savings to be targeted. They are most cost-effective in large buildings with complex building services.

Caution: A BEMS should be considered as an aid to management and not a substitute for it, and it is important that someone manages it to ensure that it operates effectively.

Building Energy Management Systems (BEMS)

BEMS are computer-based systems which automatically monitor and control a range of building services such as heating, air conditioning, ventilation and sometimes lighting. They may also provide data on energy performance to enable energy

ENERGY USE IN PRISONS, EMERGENCY BUILDINGS AND COURTS

5.1 Why analyse building energy use?

Assessing the energy performance of a building allows you to:

1. Compare performance with standards to suggest the potential for energy saving in the building.
2. Compare with other buildings in an estate or group of buildings to help identify which should be investigated first.
3. Compare with performance in previous years to monitor progress and to assess the effect of any changes or energy saving measures.
4. Consider the energy use in more depth to help understand where energy is used and wasted, and hence where savings are most likely to be made.

A general understanding of what electricity and fuels are used for in different types of building helps to concentrate attention on priority areas, especially where the use of one of the fuels is particularly high.

5.2 Types of building and their energy use patterns

This guide covers five types of building:

- Prisons
- Police stations
- Fire stations
- Ambulance stations
- Crown and Combined Courts

Typical and good examples of each type of building are used as yardsticks against which a given building can be compared.


Energy costs

Figure 5.1 shows typical annual energy costs per unit floor area for the five types of building covered in this guide.

The occupancy of court rooms can vary considerably, and the demand for cooling when the court is full can be high. There is therefore usually a need for air conditioning which explains the high cost for electricity shown in the graph.

These examples are for typical buildings. The good practice equivalents tend to use 20 to 30% less energy, mostly achieved by good management and simple measures. Still lower energy consumption is achievable in new buildings and major refurbishments.

Figure 5.1 Typical energy costs in prisons, emergency buildings and courts



Energy cost breakdown

Prisons


A typical energy cost breakdown for different end uses in prisons is shown in figure 5.2. The consumptions of energy for different purposes in any one prison may be significantly different from the typical breakdown given here. The precise split depends upon the type of prison and the extent and sophistication of equipment and services.

The "other" category includes light process energy use such as laundering or light industrial work.

This breakdown is useful for identifying areas that you should concentrate on if one or both of the performance indices (see section 6) are high.

Emergency buildings

Figure 5.3 Typical energy cost breakdown in emergency buildings




The typical proportion of energy costs for electricity and fossil fuel is similar in police stations, fire stations and ambulance stations.

The greatest energy cost will usually be for heating and hot water. Electricity costs will also be significant in many buildings, especially if there is air conditioning.


Crown and Combined courts

Figure 5.4 Typical energy cost breakdown in courts



Since electricity represents a high proportion of the energy cost in Crown and Combined courts, areas such as lighting and air conditioning should be looked at carefully for energy saving possibilities.

Figure 5.2 Typical energy cost breakdown in prisons



COMPARING WITH ACCEPTED STANDARDS - PERFORMANCE INDICES

The performance indices are obtained by dividing the annual building or site energy use by the floor area. Yardstick values for the different building types are given in figure 6.2 with electricity consumption and fossil fuel energy consumption shown separately.

The procedure is:

1. Enter the annual energy use for each fuel into column 1 of figure 6.1.
2. Multiply each fuel by the conversion factor in column 2 to get common units of energy (kWh is used for electricity and now for gas - conversion units are given in Appendix 2).

3. Enter the treated** floor area of the building in column 4.
4. Divide the energy use of each fuel by the floor area to get energy use per unit area (kWh/m²) in column 5.
5. Add the fossil fuel figures together to get a fossil fuel index - the electricity figure can be used directly.
6. Compare the indices with yardsticks for the building type in figure 6.2 to give an energy performance assessment.

Note: this does not take account of the effect of weather on heating energy use (see section 6.4).

6.1 Why use performance indices?

Performance indices give a measure of the energy use of a building which can be compared with the yardsticks. They can indicate the potential for improvements and can be used to show progress over time. They can also allow comparisons to be made between buildings in a group or estate.

6.2 Calculating the performance indices of a building and comparing to yardsticks

Two separate indices are calculated for the building, one for electricity and the other for fossil fuels. The separate indices should not be added together, because of the different cost and environmental impact of fossil fuels and electricity.

Floor area information.

The measure of floor area used to standardise energy consumption is treated** area, defined as follows in relation to the more commonly available gross and net floor areas:

Gross	Total building area measured inside external walls. These figures are often used by architects and quantity surveyors.
Net	Gross area less common areas and ancillary spaces. As used for Property Agents' lettable floor area.
Treated	Gross area less plant rooms and other areas not heated (e.g. stores, covered car parks and roof spaces).

The best available information on floor area should be entered as either ft² or preferably m² in the form below - the estimates of treated floor area can be obtained using typical ratios as shown in the form. If more than one estimate of treated area is then available, the most reliable should be used.

	ft ² ÷ 10.76 = m ²			Treated floor area
Gross floor area	<input type="text"/>	<input type="text"/>	x 0.90 =	<input type="text"/> m ²
Treated floor area	<input type="text"/>	<input type="text"/>	x 1.00 =	<input type="text"/> m ²
Net floor area	<input type="text"/>	<input type="text"/>	x 1.25 =	<input type="text"/> m ²

Annual energy consumption of your building.

This is most conveniently obtained from past bills but take care that the figures collected represent a full year and are not "estimated" by the utility. It may be helpful to look at more than one year's bills providing that there have been no significant changes to the building or its use in that time. The numbers you require are the energy units consumed, not the money value. Include all fuels: solid fuel, bottled fuel, natural gas, oil and electricity.

**Note: yardsticks for CROWN AND COMBINED COURTS are based on agent's letting area (net floor area). Other yardsticks are based on treated floor area.

Figure 6.1 Energy Performance Index Calculation

	Column 1 Annual Billed Units	Column 2 kWh* Conversion	Column 3 Annual kWh	Column 4 Treated** floor area (m ²) divide by	Column 5 Annual kWh/m ²
Gas	<input type="text"/>	kWh x 1.0	<input type="text"/>	<input type="text"/>	<input type="text"/>
Oil type	<input type="text"/>	litres x <input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Other fossil fuel	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Total of fossil fuel					<input type="text"/>
Electricity	<input type="text"/>	kWh x 1.0	<input type="text"/>	<input type="text"/>	<input type="text"/>

Note * for kWh conversion factors see Appendix 2

There may be exceptional reasons to explain a low or high consumption. For example, a building may have a low consumption because it is half empty, or a high consumption because it has extensive external lighting for security purposes.

Even a building with a low consumption may have opportunities for cost-effective improvement.

The indices show which fuel requires the most attention. The description of typical energy use patterns in section 5 may help to ascertain which use of energy is most likely to offer potential for savings. Section 4 then shows possible energy saving measures for each energy use. The next step is to select and progress suitable measures.

6.3 Overall yardsticks


Overall yardsticks based on carbon dioxide (CO₂) emissions or the cost of energy per m² of floor area can be used to provide a single performance index. These can be used to prepare league tables which compare groups of buildings or to assess buildings which have fuel supply arrangements which do not fit into the yardstick categories. This may occur, for example, in buildings with electric heating and buildings which use combined heat and power (CHP).

6.4 Refining the performance indices

If there is more information available, you may wish to assess your performance indices further in a number of ways as described in Appendix 1.

- If your building has unusual occupancy, or experiences unusual weather or exposure you may want to know their likely effect.
- You can compare your building performance with the 'Normalised Performance Indicator' used in previous editions of these guides.
- You may wish to take account of the effect of weather when comparing buildings in different parts of the country.

Figure 6.2 Energy Consumption Yardsticks



Note: yardsticks for CROWN AND COMBINED COURTS are based on agent's letting area (net floor area). Other yardsticks are based on treated floor area

A CLOSER LOOK AT ENERGY CONSUMPTION

7.1 Introduction

Often a fuller understanding of energy use in a building may be useful, for example after the initial measures have been undertaken, if there is a problem, if the building has poor performance or if it has unexpected energy bills. This section outlines techniques which you may find useful.

7.2 Monthly energy use

You can ask your supplier for monthly fuel data, or take monthly meter readings yourself.

Larger sites have monthly energy bills. By looking at how these vary with the seasons some valuable insights can be obtained. Produce a monthly consumptions bar chart plot for each energy source over a year.


The billing periods should be checked. If they are not regular, some months will appear unrealistically low and others unrealistically high. This is particularly likely in December and January. If this is the case the average daily consumption for each month can be plotted to give more accuracy.

Fossil fuel consumption, used mainly for heating, should reduce greatly in summer - to zero if it is not being used for other services such as hot water or catering.

Electricity consumption should decrease in summer in a building which is not air conditioned, because of lower lighting loads. In an air

conditioned building, peaks in spring and autumn may indicate simultaneous heating and cooling.


Example monthly fossil fuel use



The figure above shows the monthly fossil energy consumption of a fairly efficient building which has a central boiler system for heating and hot water - the summer usage is much lower than winter usage and is at a fairly steady 'base load' level which suggests that the heating is off, though it is useful to confirm this by checking that heating pumps are off, and that pipework used solely for heating is cold.

This graph shows a base load, which helps to identify the hot water load and system losses, and the heating load which depends on the weather.

Example monthly electricity use




The figure above shows monthly electricity consumption for an air conditioned building showing a small increase in the summer months as the cooling load increases. A possible small increase in winter may be due to increased lighting or some electric heating.

7.3 Relating heating use to weather

A fuel that is mainly used for heating should be used more in colder weather. The coldness of the weather can be expressed by a measure known as degree days. This shows by how much and for how long the outside temperature is below a control temperature (usually 15.5°C). Drawing a graph of fossil fuel consumption against the degree days for each month in the year shows how energy consumption is related to weather. Monthly figures for degree days for different areas of the country are published in the EEO's free bimonthly magazine 'Energy Management' (section 9.4).


Example monthly heating energy use in a well controlled building



The building represented above has a well controlled heating system shown by the close fit of the points to the straight line. As the weather gets colder the energy used goes up proportionally. For this building the energy consumption falls to a small value in summer when only hot water is being provided.

A building with better insulation would have a less steep slope because energy consumption in winter would be lower.

Example monthly heating energy use in a poorly controlled building



The figure above has a large scatter of points indicating a building with poor control. The energy use in the summer months remains higher than

the previous figure, indicating that either heating is being used unnecessarily in the summer or that the boiler and hot water systems have high losses which lead to excessive waste.

For further information see:
EEO Fuel Efficiency Booklet 7.
Degree Days

7.4 Adjusting energy use for weather

Once you know how weather conditions affect energy use, it is possible to allow for varying conditions. For example, it is possible to take account of the weather when comparing a building energy performance from year to year. Such comparisons show with greater accuracy the effect of any energy saving measures.

In order to adjust for weather it is necessary to know how much of the fossil energy is used for heating and how much is a steady base load. The base load can be estimated by looking at the monthly consumption of fossil energy as shown in section 7.2 or the graphs of fossil fuel against degree days as shown in section 7.3, and the rest is the energy used for space heating which varies with weather conditions.

CASE STUDIES

This section gives examples of measures that have been undertaken in two different buildings and resulted in energy savings. The usefulness of the Performance Index is also demonstrated, both for assessing how energy efficient a building is, and as a means of evaluating the improvement in energy performance resulting from the implementation of energy saving measures.

8.1 Loughborough Police Station

Loughborough Police Station at Southfield Road, Loughborough, Leicestershire is a three storey building built in the early 1970s. The building has brick/cavity/block walls with single glazed windows. The police station has a total floor area of 3,400m², and is staffed 24 hours per day. A series of energy efficiency improvement measures were carried

out between the years 1984 and 1986 and include:

1. Cavity wall insulation
2. Installation of 112 Thermostatic Radiator Valves (TRVs)
3. The installation of electric immersion heaters to provide hot water services during the summer
4. Insulation applied to hot water pipes and the ceiling.

The measures undertaken resulted in a 27% reduction in gas consumption, allowing for degree day correction, compared to the base year of 1984.

Cost savings and simple payback

Cost of 459,874 kWh of gas saved at 1.17p/kWh	=	£5,380
Total cost of measures	=	£10,602
Simple payback	=	2 years



Further measures were implemented between 1986 and 1990 including draught proofing and the recommissioning and adjustment of the boiler compensators. In March 1993 an energy management system was commissioned to improve the operating efficiency of the gas fired low pressure hot water heating system.

Energy Savings

The installation of the energy management system resulted in a degree day corrected saving of 17% in gas consumption. The fossil fuel performance index has improved so that it is near to the 'medium consumption' level (at 410 kWh/m²). In 1984, before any of the work was undertaken, the index was much higher, at 569 kWh/m².



Floor area = 3,400 m ²	1992	1993
Gas consumption (kWh)	1,643,546	1,424,730
Fossil fuel performance Index (kWh/m ²)	483	419

8.2 Norwich Combined Court

Norwich Combined Court houses four Crown Courts and two County Courts. Opened in 1988, it also houses facilities for the Probation Service, the Police and the Crown Prosecution Service, as well as prison staff and cells. The courts operate for five days a week and are heavily used throughout the year.

Court rooms can vary considerably in occupancy and can have very significant cooling loads when full. The majority of the building is air-conditioned, with humidification and dehumidification for the court rooms. Heating is supplied by two gas-fired boilers and cooling is provided by two reciprocating chillers.

Much of the lighting in the courts and general areas is by high pressure sodium uplighters which in larger fittings is significantly more efficient than fluorescent tubes.

Responsibility for energy management

The site engineer, with assistance from the Lord Chancellor's Departmental Energy Manager, has ensured that careful attention is paid to energy consumption. Comments made by the site engineer are shown in italic. Using a building energy management system (BEMS) the site engineer began to monitor the operation of the building to identify comfort levels, plant operation and the resulting energy demands.

"You must keep a track of what is being used. I like to keep graphical records as it allows a clear comparison with historical records and you can see the effect of the savings."

Staff involvement

Involvement of all staff in the courts has been very beneficial.

"I inform staff of what I am doing with reasons why, and as a result I receive a good response."

Court ushers were asked to switch lights off when courts are not occupied and this has proved to be very successful.

Low cost energy saving measures

The first priority was to identify and implement some low capital cost measures.

Tariff negotiation

Electricity tariffs were renegotiated and a system of shedding electrical loads at peak times to reduce maximum demand charges was introduced.

Optimising controls

The co-operation from ushers was essential so that the site engineer knew the times when courts were being used.

It was found that a great deal of plant could be switched off over lunch periods and when courts finished early. On some days individual courts were not sitting at all. A series of override switches were installed to allow plant to be shut down manually when courts are not in session.

Duty cycling was introduced on much of the air handling plant. Using the BEMS, fans are switched off automatically for about 10 minutes every half hour without a detrimental effect on comfort conditions.

All the air handling plant recirculates variable amounts of conditioned air depending upon inside conditions. Most of the units also have free cooling control, which avoids running cooling plant by taking advantage of cold outside air.

In 1990, a further modification was made to the air conditioning control regime. Previously, general air conditioning which was needed for staff areas automatically also brought on the associated court room air conditioning. These systems were separated so that it is possible to further minimise court room air conditioning when courts are not in use.

Automatic flush controls

Automatic urinal flush controls were fitted in the men's toilets to control the frequency of flushing. This measure halved the total water consumption to 50,000 litres/wcek.

The savings achieved from all of these measures have been substantial without a detrimental effect on comfort.

Monitoring and targeting

The site engineer's graphs of energy use alerted him to increased consumption during 1992 owing to more intensive use of the courts. Action was taken by fine tuning air conditioning controls whilst carefully monitoring the results in terms of energy consumption and comfort conditions.

Energy Management

The levels of savings achieved at Norwich Combined Court are a reflection of the level of commitment of the site engineer to control energy costs. Plant is maintained and operated effectively and energy saving opportunities are pursued when they occur. When an energy survey was carried out in 1993 it confirmed that this had been effective.

Improvement in performance indices

Agent's letting area = 5,421 m²

	Fossil Fuel Index (kWh/m ² /yr)	Fossil Fuel Performance Assessment	Electricity Index (kWh/m ² /yr)	Electricity Performance Assessment
Before low cost measures	161	Low consumption	93	Low consumption
After low cost measures	142	Low consumption	84	Low consumption

8.3 Energy savings from cavity wall insulation and heating controls in a fire station

The Eastern Fire Station at Hastings Road, Leicester, has a total floor area of 747m², a staff of 55 and is manned 24 hours a day. During 1986, an integrated package was implemented to reduce heating costs. Cavity wall insulation was installed at a cost of £768 and heating controls were refurbished. The controls included the installation of thermostatic radiator valves and the provision of a weather compensator. Both these measures act to match the heating level to the demand which is determined by the weather. These controls also improve comfort of staff. The total cost of these heating controls was £2,867.

The measures undertaken at Eastern Fire Station resulted in an improvement in performance rating for the heating from medium consumption (between 385 and 540 kWh/m²/yr) to low consumption (under 385 kWh/m²/yr).



Energy and cost savings

The reduction in gas consumption of 94,788 kWh is equivalent to an annual saving of £1,175 at January 1987 fuel prices. The total cost of the measures was £3,635, giving a payback of 3 years.

The 25% reduction in gas consumption at Eastern Fire Station demonstrates the benefit of improved fabric insulation combined with the provision of good heating controls.



Total Floor Area = 747m²

	Fossil Fuel Index (kWh/m ² /yr)	Fossil Fuel Performance
Before Measures	500	Medium consumption
After Measures	375	Low consumption

ADVICE AND HELP

9.1 The Energy Efficiency Office

The Energy Efficiency Office (EEO) is part of the Department of the Environment.

The EEO currently aims to achieve environmental and economic benefits by promoting cost effective energy efficiency measures in the industrial, commercial, domestic and public sectors of the economy by:

- Raising awareness
- Identifying and overcoming barriers to action
- Providing financial incentives where appropriate
- Regulation where necessary
- Providing technical advice.

9.2 Best Practice Programme

The EEO's Best Practice programme gathers and disseminates authoritative information on cost effective energy saving measures. The Best Practice programme for buildings is managed on behalf of the EEO by the Building Research Energy Conservation Support Unit (BRECSU) and for industry by the Energy Technology Support Unit (ETSU).

A range of publications is available under the Best Practice programme, normally free of charge. Relevant titles for prisons, emergency buildings and courts are listed here.

Good Practice Guides give advice on how to implement energy saving measures. Relevant titles are as follows:

- 3 Introduction to small scale combined heat and power
- 35 Energy efficient options for refurbished offices

- 46 Heating and hot water systems in offices
- 71 Selecting air conditioning systems
- 84 Managing and motivating staff to save energy
- 117 Energy efficiency in the government estate - for accommodation managers.

General Information Leaflets and Reports also give advice on how to implement energy saving measures. Relevant titles are as follows:

- 1 The success of condensing boilers in non-domestic buildings. A user study

Information on energy management is contained in these General Information Reports:

- 12 Organisational aspects of energy management
- 13 Reviewing energy management
- 14 Energy management of buildings including a review of some case studies.

Fuel Efficiency Booklets are working manuals which provide detailed technical guidance on specific areas of energy use in buildings and industry. Relevant booklets are:

- 1 Energy audits for buildings
- 7 Degree days
- 0 The economic thickness of insulation for hot pipes
- 9 Economic use of electricity in buildings
- 10 Controls and energy savings
- 12 Energy management and good lighting practices.

In addition, a wide range of events is organised to promote the results of the Best Practice programme. These include seminars, workshops and site visits and are targeted at different sectors and professionals.

Details of publications and events can be obtained from:

BRECSU (for buildings)
Building Research Establishment
Garston
Watford WD2 7JR
Tel: 0923 664258
Fax: 0923 664097

ETSU (for industrial sectors)
Harwell
Didcot
Oxon OX11 0RA
Tel: 0235 436747
Fax: 0235 432923

9.3 Other publications available from BRECSU

Energy Efficient Lighting in Offices (1993). A THERMIE Maxibrochure

9.4 Free Publications From the EEO

The Introduction to Energy Efficiency series. There are 13 Guides in this series, of which this is one:

Catering establishments
Entertainment buildings
Factories and warehouses
Further and higher education
Health care buildings
Hotels
Libraries, museums, galleries and churches
Offices
Post Offices, banks and agencies
Prisons, emergency buildings and courts
Schools
Shops
Sports and recreation centres

Choosing an Energy Efficiency Consultant (EMAS 2)

Practical Energy Saving Guide for Smaller Businesses (ACBE 1).

The above are all available from:
Department of the Environment
Blackhorse Rd
London SE99 6TT
Tel: 081 691 9000

The 'Energy Management' journal.

Published bi-monthly and available from the EEO.
Tel: 071 276 6200

9.5 Other EEO Programmes

Making a Corporate Commitment Campaign

The 'Making a Corporate Commitment' campaign seeks board level commitment to energy efficiency. It encourages directors to sign a Declaration of Commitment to responsible energy management, prepare a business plan for energy efficiency and ensure that it becomes an item that is considered regularly by their main board.

Publications:

Chairman's Checklist
Executive Action Plan
Energy, Environment and Profits - Six case studies on corporate commitment to energy efficiency.

Further information is available from the Campaign Offices on
Tel: 071 276 4613.

Energy Management Assistance Scheme

The Energy Management Assistance Scheme may provide support for small and medium sized businesses (up to 500 employees) to employ an energy consultant. This aims to upgrade the expertise in energy efficiency among smaller companies, and tackle the capital priority barrier through financial support.

Further information can be obtained on 071 276 3787.

9.6 Sources of Free Advice and Information

Regional Energy Efficiency Officers

11 Regional Energy Efficiency Officers (REEOs) around the UK can provide copies of all the EEO's literature and give specific advice on:

- opportunities for better energy efficiency in your organisation
- technologies and management techniques you should be thinking about
- appropriate sources of specialist advice and assistance in the private sector
- EEO programmes
- regional energy managers' groups

REEO Northern Region
Wellbar House
Gallowgate
Newcastle Upon Tyne NE1 4TD
Tel: 091 201 3343

REEO Yorkshire and Humberside
City House
New Station Street
Leeds LS1 4JD
Tel: 0532 836 376

REEO North West
Sunley Tower
Piccadilly Plaza
Manchester M1 4BA
Tel: 061 838 5335

REEO East Midlands
Cranbrook House
Cranbrook Street
Nottingham
Nottinghamshire NG1 1EY
Tel: 0602 350 602

REEO West Midlands
Five Ways Tower
Frederick Road
Birmingham B15 1SJ
Tel: 021 626 2222

REEO Eastern
Heron House
49-53 Goldington Road
Bedford MK40 3LL
Tel: 0234 276 194

REEO South West
Tollgate House
Houlton Street
Bristol BS2 9DJ
Tel: 0272 218 665

REEO South East
Charles House
Room 565
375 Kensington High St
London W14 8QH
Tel: 071 605 9160

REEO Scotland
New St Andrews House
Edinburgh
Scotland EH1 3TG
Tel: 031 244 1200

REEO Wales
Cathays Park
Cardiff
Wales CF1 1NQ
Tel: 0222 823 126

REEO Northern Ireland
Dept of Economic Development
Netherleigh House
Massey Avenue
Belfast
N Ireland BT4 2JT
Tel: 0232 529900

9.7 Other Programmes

Energy Design Advice Scheme

The Energy Design Advice Scheme is a Department of Trade and Industry discretionary initiative aimed at improving the energy and environmental performance of the building stock by making low energy building design expertise more accessible for the energy efficient design and refurbishment of buildings. The scheme offers support, via a number of Regional Centres, to design teams or clients in the energy aspects of design of new buildings or refurbishment projects over 500m² gross area.

Further information can be obtained from the following Regional Centres:

For Scotland
Tel. 031 228 4414

For South East England
Tel. 071 916 3891

For Northern England
Tel. 0742 721 140

For Northern Ireland
Tel. 0232 364 090

EU Programmes

Several EU programmes aimed at demonstrating energy efficiency measures and encouraging energy efficiency R&D. Details change periodically. For further information contact BRECSU for buildings and ETSU for industry.

9.8 Other Publications

Chartered Institution of Building Services Engineers (CIBSE):

CIBSE Applications Manual, AM 5:1991,
Energy Audits and Surveys

CIBSE Applications Manual, AM 6:1991,
Contract Energy Management

CIBSE Applications Manual, AM3, Condensing
Boilers

CIBSE Applications Manual, AM8, Private and
Standby Generation of Electricity

CIBSE Code for Interior Lighting (1984)

CIBSE Lighting Guide 3(LG3)(1989).
Areas for Visual Display Terminals

Available from:

CIBSE, 222 Balham High Rd,
Balham,
London SW12 9BS.
Tel: 081 675 5211
Fax: 081 675 5449

Heating and Ventilating Contractors Association (HVCA):

Standard Specification for Maintenance of
Building Services. Volumes 1 - 5. 1990 -
1992.

Available from:

HVCA Publications, Old Mansion
House, Earmont Bridge, Cumbria,
CA10 2BX
Tel: 0768 64771

9.9 Other Useful Addresses

Energy Systems Trade Association
Ltd (ESTA)
PO Box 16, Stroud, Gloucestershire
GL5 5EB
Tel: 0453 886776; Fax: 0453 885226

Major Energy Users' Council
10 Audley Road
London W5 3ET
Tel: 081 997 2561/3854
Fax: 081 566 7073

APPENDIX 1

Development of Building Performance Indices (PI)

Introduction

This section outlines how to calculate environmental and cost indices for the energy used in your building. It describes the effect of weather, building occupancy and exposure on the performance of a building, with a method to allow for these factors if required.

Adjustments of the PI for these factors produces a 'Normalised Performance Index' (NPI) which is compatible with earlier versions of this guide. For many purposes, the effect of these factors on performance indices is small enough to be ignored.

Overall performance indices

Overall performance indices provide a single measure of building performance, and can be expressed in terms of carbon dioxide (CO₂) emissions or energy cost. Overall energy indices are useful for comparing a stock of buildings or for assessing the performance of buildings with electric heating or combined heat and power (CHP). However, separate fossil fuel and electricity performance indices are more useful to assist in deciding a course of action.

To calculate overall performance indices you need the annual energy use indices as obtained in figure 6.1 and conversion factors for each of the fuels - some of which are given in figures A1.1 and A1.2. The calculation procedure is to enter the kWh/m² figure in Column 1, and multiply by the relevant conversion factors in column 2 to get either the kg of CO₂ per m² or the cost per m² in column 3.

The conversion factors shown are broadly representative of the current fuels used in these buildings, and can be used if a consistent set of factors is required. CO₂ factors, particularly for electricity, may vary from this data. Cost factors will also vary over time and as a function of use. Energy unit costs in larger buildings tend to be cheaper than for smaller supplies. You may wish to use your own costs from your own bills instead of those given here.

Overall yardsticks for CO₂ emissions or energy costs can also be calculated, by inserting yardstick energy consumptions (given in figure 6.2) into column 1. These can be compared with the actual index for your building to give an overall assessment. CO₂ and cost yardsticks calculated on the basis that the fossil fuel is gas are presented in figure A1.3.

Effect of weather on energy use

Weather changes from year to year for a given site cause variations in fossil/heating energy use of typically ±5% from the average values or ±10% in more extreme years.

Weather differences across the country cause variation in heating requirements of typically ±10% from average values and ±20% in more extreme areas.

The effect on electricity use will be small unless electricity is used for space heating, or in air conditioned buildings where the cooling energy will be higher during a warm summer.

Exposure

If a building is very exposed (on an exposed hill for example), heating energy increases by 5-10% and likewise a completely protected building may use 5-10% less. In many cases steps will have been

taken on exposed buildings to improve draught sealing which will offset the increase. Electricity use is largely unaffected except in electrically heated buildings.

Hours that the building is occupied (occupancy)

Occupancy affects buildings' energy use in different ways for different systems. Heating energy in a naturally ventilated heavy building varies very little with occupancy - say 5%. If a building has a light weight structure, or is mechanically ventilated or air conditioned, the heating energy may increase in more direct proportion to the occupied hours, giving 20% variation or more from the typical occupancy.

Electricity consumption of a badly controlled building will be almost independent of the occupancy, owing

Figure A1.1
CO₂ Performance Index Calculation

	Column 1 Annual energy use kWh/m ²	Column 2 CO ₂ conversion* factors kg/kWh	Column 3 Annual CO ₂ emissions kg/m ²
Gas	<input type="text"/>	x 0.20	<input type="text"/>
Oil	<input type="text"/>	x 0.29	<input type="text"/>
Coal	<input type="text"/>	x 0.32	<input type="text"/>
Electricity	<input type="text"/>	x 0.70	<input type="text"/>
Total CO₂ emissions per m²			<input type="text"/>

*typical 1993 emission factors

Figure A1.2
Cost Performance Index Calculation

	Column 1 Annual energy use kWh/m ²	Column 2 Cost conversion factors £/kWh*	Column 3 Annual £/m ²
Gas	<input type="text"/>	x 0.014	<input type="text"/>
Oil	<input type="text"/>	x 0.012	<input type="text"/>
Coal	<input type="text"/>	x 0.009	<input type="text"/>
Electricity	<input type="text"/>	x 0.071	<input type="text"/>
Total energy cost per m²			<input type="text"/>

*typical 1992 prices

to lights and services left on from early morning to last thing at night. But for a well controlled building, both lights and plant may operate in direct proportion to occupancy.

Normalised performance indices

It is possible to adjust (normalise) performance indices for weather, exposure and extended occupancy, but care is needed as incorrectly applied adjustments, or adjustments that are too simplistic, may introduce larger errors than the typical variations discussed above. For example, the effect of extended hours of use on energy consumption can easily be exaggerated, making the building performance seem better than is really the case.

Note also that while a normalised performance index is a better measure of a building's efficiency than an unnormalised index, the latter shows the building's actual performance. So a building with a low normalised performance index, but a high performance index before adjustment, is efficient, but since it is still a high user of energy, it may well offer good opportunities for cost effective energy saving.


The worksheet in figure A1.4 can be used to obtain performance indices which are normalised to standard conditions of weather, exposure and occupancy. This is useful if:

- You require normalised performance indices for compatibility with previous work
- Any of the factors cause significant errors (see above sub sections to evaluate this).

A normalised performance index based on overall CO₂ emissions or energy cost is obtained by using figure A1.1 or A1.2 and inserting the normalised performance indices for each fuel into Column 1. If more than one fuel is used for heating, calculate a separate normalised performance index for each fuel first and then use this procedure.

Figure A1.3

Carbon dioxide and cost yardsticks



Performance indices - summary

- Simple performance indices are for initial energy assessments. Separate performance indices are calculated, one for fossil fuels and one for electricity use, and no adjustments are made.
- Overall performance indices, based on carbon dioxide (CO₂) or cost, are normally used when the energy supply arrangement is not typical or when a number of buildings are to be compared. Also, you may want to know the cost or the CO₂ performance for a single building.

- Normalised performance indices are used when more sensitive comparisons are required and the effect of factors such as weather and occupancy become significant. But if you choose to normalise, be aware of introducing errors.

Figure A1.4

Normalised Performance Indices calculation

	Fossil fuel				Total of	
	Gas	Oil	Other		Fossil Fuels	Electricity
Total energy consumption (kWh)	<input type="text"/>	<input type="text"/>	<input type="text"/>	(A)	<input type="text"/>	<input type="text"/>
Space heating energy (kWh)	<input type="text"/>	<input type="text"/>	<input type="text"/>	* (B)	<input type="text"/>	<input type="text"/>
Non space heating energy (kWh)	<input type="text"/>	<input type="text"/>	<input type="text"/>	A-B = (C)	<input type="text"/>	<input type="text"/>
Find the degree days for the energy data year				* (D)	<input type="text"/>	
Weather correction factor = $2462 \div D =$				(E)	<input type="text"/>	
Obtain the exposure factor below				* (F)	<input type="text"/>	
Obtain occupancy factor for heating energy use from below				* (G)	<input type="text"/>	
Annual heating energy use for standard conditions				B x E x F x G = (H)	<input type="text"/>	<input type="text"/>
Obtain occupancy factor for non-heating energy from below				* (K)	<input type="text"/>	
Annual non-heating energy use = $C \times K =$				(L)	<input type="text"/>	<input type="text"/>
Normalised energy use = $H + L =$				kWh (M)	<input type="text"/>	<input type="text"/>
Find floor area				m ² (N)	<input type="text"/>	<input type="text"/>
Find the Normalised Performance Indices = $M \div N =$				kWh/m ² (P)	<input type="text"/>	<input type="text"/>

*Notes:

(B) Estimation of weather-dependent heating energy use is discussed in section 7.

(D) For degree day information, see Fuel Efficiency Booklet 7 - Degree Days

Monthly degree day figures are published in 'Energy Management' (see section 9.4)

(F) Exposure factors from figure A1.5.

(G) and (K) Occupancy factors from figure A1.6.

Figure A1.5
Exposure factor

	Factor
Sheltered. The building is in a built-up area with other buildings of similar or greater height surrounding it. This would apply to most city centre locations.	1.1
Normal. The building is on level ground in urban or rural surroundings. It would be usual to have some trees or adjacent buildings.	1.0
Exposed. Coastal and hilly sites with little or no adjacent screening.	0.9

Figure A1.6
Occupancy Factors

	Factor for heating energy (G)	Factor for non-heating energy (K)
Normal building occupancy:		
Courts (5 days, 10 hours per day)	1.00	1.00
Other buildings 24 hours/day		
Lightweight court building		
Extended occupancy	0.85	0.80
Other court buildings		
Extended occupancy	0.95	0.80


APPENDIX 2

Energy Conversion Factors

The unit of energy used in this guide is the kilowatt - hour (kWh). One kilowatt - hour is consumed by a typical one bar electrical fire in one hour. For fuels which are metered in other units, multiply the metered value by the relevant conversion factor from the following table to obtain the value in kWh.

Figure A2.1
Conversion to kWh

	kWh conversion
Light Fuel Oil	11.2 kWh/litre
Medium Fuel Oil	11.3 kWh/litre
Heavy Fuel Oil	11.4 kWh/litre
Gas Oil (35 second)	10.8 kWh/litre
Kerosene - burning oil 22 second	10.4 kWh/litre
Electricity	[Metered directly in kWh]
Natural gas	29.31 kWh/therm
Liquid Petroleum Gas (LPG) (Propane)	6.96 kWh/litre
Coal (washed shingles)	7,900 kWh/tonne
Coal (washed smalls)	7,800 kWh/tonne





Energy Efficiency Office
DEPARTMENT OF THE ENVIRONMENT